

Oral Inflation and Deflation Instructions

Proper usage is essential to preventing damage!

Oral Inflation

To orally inflate the PFD, first locate the oral inflation tube by opening the wearer's right front panel cover of the PFD. Then remove the dust cap from the end of the oral tube and blow into the tube until the PFD is fully inflated. It may be necessary to manually release the Velcro™ tabs for full inflation because oral inflation may not provide sufficient pressure to open the tabs.

WARNING: CO₂ inflation could over-pressurize and damage your PFD if already orally inflated!

Deflation

To deflate the PFD, reverse the oral inflation tube dust cap and insert it into the valve. The dust cap will not lock in the deflation position so it is necessary to hold it in place. Gently squeeze the PFD until all air or gas has been expelled. Do not ring or twist the PFD.

WARNING: Using something other than the dust cap to depress the valve could cause the valve to malfunction!

